

## **PM CHECK LIST** Sterilizer PM Kit (RPI Part #PCK220) for parts to fit the Validator<sup>®</sup> 8 sterilizer

PART	RPI PART #	STERILIZER PM TIP
Door Gasket	PCG065	Remove the old door gasket. Clean the gas- ket groove and chamber face ring surface. For easy install of the new gasket, use the "star" or "North-South-East-West" method (ie. begin installing the gasket at the top of the door, then the bottom, then the left side, then the right side, and then everything in between making sure that the gasket fits flush without bumps or gaps).
Door Spacer	PCS067	Take CAUTION when removing or installing the door spacer – the doors tabs can be sharp. To install door spacer, place the spacer on and over the door tabs. The spac- er MUST lie flat against the door.
Bellows O-ring	PCB001 RP0354	Unscrew the bellows cap through the access port at the rear of the sterilizer or remove sterilizer cover. Clean out air valve housing. Use a cotton swab to clean the seat. Install the new bellows with the new oring – do not overtighten the bellows cap.
Filter Fill Line (Chamber)	PCF009	Remove all trays from the chamber. Remove the chamber filter. Clean chamber. Install new filter making sure that it is placed at the bottom and center of the chamber.
Sterilizer	_	After replacing the PM parts: • Check the reservoir and clean if dirt or debris are present (Note: Debris is the num- ber one reason for Steam Trap/Bellows fail- ure). • Refill reservoir with distilled water only. • Conduct a temperature check using a Max Register Thermometer (RPI Part #RPT113). • Conduct a pressure check to identify any leaks that may need to be addressed.

