

PM CHECK LIST

Sterilizer PM Kit (RPI Part #PCK231) for parts to fit the Delta AE8, XL8 and Q8 sterilizers

PA	ART	RPI PART #	STERILIZER PM TIP
Do	oor Gasket	PCG065	Remove the old door gasket. Clean the gasket groove and chamber face ring surface. For easy installation of the new gasket, use the "star" or "North-South-East- West" method (ie. begin installing the gasket at the top of the door, then the bottom, then the left side, then the right side, and then everything in between making sure that the gasket fits flush without bumps or gaps).
Do	oor Spacer	PCS067	Take CAUTION when removing or installing the door spacer – the door's tabs can be sharp. To install door spacer, place the spacer on and over the door tabs. The spacer MUST lie flat against the door.
	lter - Fill Line intered Bronze)	PCF009	Remove all trays from the chamber. Remove the chamber filter with the fill chamber tube. Clean chamber. Install new filter with the fill chamber tube, making sure that it is placed at the bottom and center of the chamber.
	lter In-Line Assembly creen Type)	PCF233	Remove Filter In-Line Assembly, located to the left of the Filter - Fill Line (RPI Part #PCF009), by pulling the small stainless steel handle. Install new filter by push- ing it in to the Chamber Port.
	eservoir Filter Kit intered Bronze)	PCK167	Remove the sterilizer cover, drain and clean the reservoir if necessary when removing the old reservoir filter. Be sure to install the new o-ring when installing the new filter. Refill with distilled water only.
☐ HE	EPA Filter	RPF644	Locate HEPA Filter and cut cable tie. Note the direction of the arrow on the filter and remove tubing. Install new filter in the same direction as the old filter and mount with a new cable tie.
□ Co	ompressor Filter	SCF002	Remove pump filter cover. Remove filter and clean out any dust or debris. Replace filter and the cover.
St	erilizer	-	After replacing the PM parts: • If you have not yet checked and cleaned the Chamber and Reservoir, do so at this time. (Note: Debris is the number one reason for Solenoid Valve failure). • Refill reservoir with distilled water only. • Conduct a tem- perature check using a Max Register Thermometer (RPI Part #RPT113). • Conduct a pressure check to identify any leaks that may need to be addressed.



replacement parts industries, inc.

CALL (800) 221-9723 or (818) 882-8611 • FAX (818) 882-7028 E-MAIL order@rpiparts.com • WEBSITE www.rpiparts.com

The above parts are manufactured by Replacement Parts Industries, Inc. to fit Pelton & Crane equipment. All product names used in this document are trademarks or registered trademarks of their respective holders. PCK231INS REV A (11/09)